




CP2102+ZT213 USB RS232-DB9 male(nuts)



EHS6T
USB/LAN:



1	2	3	4	1	2	3	4	5	6
GPIO6	GPIO7	GPIO8	GPIO11	VCCref	GND	TXD1/ SPI_MISO	RXD1/ SPI_MOSI	CTS1 (RS232)/ SPI_CS	RTS1 (RS232/)
5	6	7	8	7	8	9	10	11	12
GPIO12	GPIO13	GPIO22	GPIO23	+5Vout	DSR0/ ADC1_IN/ SPI_CLK	I2CDAT	I2CCLK	GPIO20	GPIO21